

CATALOG OF LOHIA STARLINGER MODEL : LS-FIL-23 CHEESE WINDER SPARES

1.		GUIDE BUSH F23 0300 07	2.		SPECIAL WASHER F23 0400 02
3.		DRIVEN DISC F23 0400 03	4.		INT. CIRCLIP F23 0400 05
5.		PULLEY F23 0400 04	6.		BALL BEARING F23 0400 06
7.		PARALLEL KEY F23 0400 07	8.		EXT. CIRCLIP F23 0400 08
9.		GUIDE BUSH F23 0400 09	10.		SPINDLE SHAFT F23 0400 10
11.		SPRING F23 0400 11	12.		SCREW F23 0400 01
11.		SCREW F23 0401 03	12.		DOWEL PIN F23 0401 02

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

13.		SPECIAL WASHER F23 0401 03	14.		CONE BACK F23 0401 04
15.		RING EXPANDER FRONT F23 0401 05	16.		SPRING FOR SPINDLE F23 0401 06
17.		CHEESE FRONT F23 0401 07	18.		RING EXPANDER REAR F23 0401 08
19.		SPACER F23 0401 09	20.		HEX NUT F23 0401 10
21.		SCREW F23 0500 01	22.		WASHER F23 0500 02
23.		SINTERED BUSH F23 0500 04	24.		SHAFT F23 0500 04
25.		BEARING BLOCK F23 0500 07	26.		HEX NUT F23 0500 08






-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

27.		LEVER BAR F23 0500 09	28.		HEX NUT F23 0500 10
29.		BALL SHAPED HEAD F23 0500 01	30.		LEVER BAR HOLDER F23 0500 12
31.		DRIVING DISC MAGNET DISC F23 0600 01	32.		MAGNET F23 0600 02
33.		CUP FOR MAGNET F23 0600 03	34.		SCREW BRASS F23 0600 04
35.		MOTOT F23 0600 07	36.		SCREW F23 0600 06
37.		WASHER F23 0600 05	38.		NUT F23 0600 08
39.		WASHER F23 0600 09	40.		PARALLEL KEY F23 0600 10
41.		SCREW F23 0600 11	42.		SLEDGE F23 0700 02

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
 AHMEDABAD-380004. Gujarat, INDIA.

43.		CAM FOLLOWER ROLLER F23 0700 03	44.		CAM FOLLOWER F23 0700 04
45.		AL. FLANGE BACK F23 0700 05	46.		HEX NUT F23 0700 04
47.		CAM F23 0700 08	48.		TIE ROD F23 0700 09
49.		GUIDE ROD F23 0700 12	50.		STEEL PIPE F23 0700 13
51.		BALL BEARING F23 0700 14	52.		RUBBER WASHER F23 0700 15
53.		SPECIAL WASHER F23 0700 16	54.		NYLOCK NUT F23 0700 17
55.		SCREW F23 0700 19	56.		CAM SHAFT F23 0700 20
57.		INT. CIRCLIP F23 0700 21	58.		BALL BEARING F23 0700 22

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

59.		AL. FLANGE F23 0700 10	60.		SPECIAL WASHER F23 0700 23
61.		CHUCK NUT KM-8 F23 0700 24	62.		BEARING BOLT F23 0803 01
63.		BEARING SUPPORT F23 0803 02	64.		BALL BEARING F23 00803 03
65.		PRESSURE ROLLER F23 00803 04	66.		BEARING BOLT FRONT TYPE-I F23 0803 05
67.		BEARING BOLT FRONT TYPE - II F23 0803 05	68.		EYE FOR FINGER GUIDE F23 0803 06
69.		NUT F23 0803 08	70.		WASHER F23 0803 09
71.		FINGER GUIDE F23 0803 10	72.		SCREW F23 0803 11
73.		PLASTIC COVER F23 0803 12	74.		FINGER GUIDE BASE F23 00803 13
75.		SCREW F23 0803 14	76.		SCREW F23 0803 15



















-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
 AHMEDABAD-380004. Gujarat, INDIA.

77.		EXTRACTION NUT F23 00803 16	78.		NUT F23 0803 17
79.		OIL CHECK SCREW F23 0900 05	80.		WASHER F23 0900 02
81.		SCREW F23 0900 01	82.		GUIDE SHEET F23 0900 03
83.		HEX NUT F23 0900 04	84.		OSCILLATING ROD F23 0900 06
85.		SCREW F23 0900 07	86.		SINTERED BRONZE BUSH F23 0900 08
87.		TORSION SPRING LEFT F23 0900 09	88.		TORSION SPRING RIGHT F23 0900 12
89.		GRUB SCREW F23 0900 11	90.		BUSH FOR TROSION SPRING F23 0900 11
91.		SCREW F23 0900 13	92.		LEVER F23 0900 14
93.		SCREW F23 0900 17	94.		BRAKE SHOE ROD F23 0900 18

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

95.		CYLINDRICAL PIN F23 0900 20	96.		BRAKE SHOE F23 0900 21
97.		GUIDE F23 0900 19	98.		SCREW F23 0900 22
99.		WASHER F23 1003 04	100.		FLAT BELT 550mm X 12mm F23 1003 05
101.		BRG. PULLEY SUPP. F23 1003 06	102.		BALL BEARING F23 1003 07
103.		SPACER F23 1003 08	104.		INT. CIRCLIP F23 1003 09
105.		PLATE F23 1003 10	106.		PULLEY SMALL F23 1003 11
107.		SPL. WASHER F23 1003 12	108.		SCREW F23 1003 13
109.		SPL. WASHER F23 1004 14	110.		CHUCK NUT F23 1003 15
111.		GEAR - 30 T F23 1003 16	112.		GEAR - 63 T F23 1003 18

-: Registered Office Address :-











7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



113.		WASHER F23 0900 23	114.		NUT F23 1003 01
115.		WOODRUFF KEY F23 1003 12	116.		AXLE F23 1003 03
117.		WASHER F23 1003 04	118.		SHIM F23 1003 20
119.		STAR KNOB F23 1100 01	120.		GUIDE ROLLER F23 1301 11
121.		SCREW F23 1301 04	122.		WASHER F23 1100 09
123.		NUT F23 1100 08	124.		SCREW F23 1301 07
125.		INT. CIRCLIP F23 1301 08	126.		EXT. CIRCLIP F23 1100 12
127.		WASHER F23 1100 06	128.		PARALLEL KEY F23 1202 05
129.		SPACER F23 1301 10	130.		SCREW F23 1301 03

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

131.		EYE FOR J HOOK F23 1401 14	132.		J HOOK SUPPORT SINGLE F23 1401 11
133.		J HOOK SUPPORT DOUBLE F23 1401 11	134.		SCREW F23 1301 07
135.		SET SCREW F23 1100 02	136.		FORK SPRING F23 1100 04
137.		GUIDE POST F23 110010	138.		ADJUSTING LEVER F23 1202 06
139.		CONNECTING ARM F23 1202 16	140.		ACTUATING LEVER F23 1301 01

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

