

CATALOG OF LOHIA STARLINGER LTD. MODEL : HDN-4 CIRCULAR LOOMS SPARES

1.		LOWER HEDDLE BELT N4 024 5 019	2.		UPPER HEDDLE BELT N4 024 5 007
3.		HEDDLE BELT N4 024 3 000	4.		HEDDLE BELT OLD MODEL
5.		SHUTTLE WHEEL N4 013 10 017 N4 0904 08	6.		CAM ROLLER-40MM Ref : N4 024 8 004 Ref : N4 024 9 004
7.		ROLLER/BANDAGE PU N4 020 2 010	8.		SWINGING LEVER N4 024 8 016 N4 024 9 016
9.		JOCKEY LEVER N4 024 8 022 N4 024 9 022	10.		CONNECTING PLATE N4 024 5 017
11.		CONNECTING STRIP N4 024 5 016	11.		BELT PULLEY N4 024 8 012 N4 024 9 012
13.		SINTERED BUSH N4 024 8 017 N4 024 9 017	14.		SHUTTLE BODY N4 013 10 034 N4 013 38 016 N4 0901 09
15.		CHONCHOID ROLLER N4 013 10 031 N4 0904 06	16.		INSERTION FINGER HOLDER N4 0902 07 N4 013 10 007 N4 0905 14

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



17.		COVER/ SHUTTLE NOSE N4 013 10 003 N4 0901 03	18.		BRAKING NYLON N4 013 30001 N4 0909 01
19.		BRAKE BEARING N4 013 30004 N4 0909 04	20.		DEFLECTING PULLEY N4 024 5 006
21.		HOLDER ASSY. N4 013 22015 N4 013 36016 N4 0905 033	22.		REFLECTOR HOLDER N4 013 22017 N4 013 36018 N4 013 39004 N4 0905 08
23.		DISC N4 2316 01	24.		TUBE WITH FEATHER DIA 35 N4 2316 03
25.		PUSHER BLOCK N4 020 2 005	26.		EXCETER BOLT Ref : N4 0950 08
27.		GUIDE BRACKET HOLDER N4 013 10 005 N4 0901 07	28.		ROLLER FLANGE N4 020 2 008
29.		SPACER N4 009 3009 N4 1100 09	30.		BUSH N4 2310 03 N4 039 3 003 N4 231602
31.		CAP N4 024 8 001 N4 024 9 001	32.		BEARING BLOCK N4 024 5 002
33.		SPRING LOADED ARM N4 013 30007 N4 0909 07	34.		SPRING STRETCHER N4 013 30012 N4 0909 11

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

35.		BOBBIN HOLDER N4 013 22 002 N4 013 36 002 N4 013 37 002 N4 013 38 002 N4 013 40 007	36.		BOBBIN HOLDER N4 013 22 012
37.		COVER N4 013 22 008 N4 013 36 008 N4 013 37 008 N4 013 38 008	38.		BOBBIN HOLDER N4 013 36 013 N4 013 37 012 N4 013 38 012 N4 013 40 010
39.		SUPPORT N4 013 10 006 N4 0901 04	40.		COVER N4 013 36 010 N4 013 37 010 N4 013 38 010 N4 013 40 013
41.		BUSH F. SPRING N4 013 30008 N4 0909 08	42.		COVER N4 013 10 026 N4 0904 01
43.		WHEEL COVER N4 013 10 013 N4 0904 10	44.		CAP N4 0801 16
45.		SHUTTLE BRACKET N4 013 10 004 N4 0901 08	46.		BRAKE ARM N4 013 10 047 N4 0901 10
47.		SHAFT N4 024 8 020 N4 024 9 020	48.		SHAFT N4 024 8 011 N4 024 9 011
49.		INSERTION FINGER N4 013 10 008 N4 0902 01 N4 0905 01	50.		INSERTION FINER (20-40 CM DFL) N4 0902 10 N4 0905 15

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



51.		INSERTION FINGER (60-80 CM DFL) N4 0902 11 N4 0905 16	52.		PIN N4 024 5 018
53.		REED ROLLER N4 023 1 009	54.		BEARING HOUSING N4 023 1 005
55.		SPL. WASHER N4 023 1 007	56.		PIN N4 013 22014 N4 013 36 015 N4 013 39 001 N4 0905 04
57.		SCREW N4 024 5 008	58.		SCREW N4 024 8 002 N4 024 9 002
59.		AXLE N4 013 22007 N4 013 36 007 N4 013 37 007 N4 013 38 007 N4 013 40 001	60.		SCREW N4 020 2 012
61.		SPACER N4 024 8 015 N4 024 9 015	62.		SPACER N4 013 36 009 N4 013 37 009 N4 013 38 009 N4 013 40 014
63.		AXLE N4 024 5 011	64.		SCREW N4 013 36 014 N4 013 37 013 N4 013 38 013 N4 013 40 009
65.		BOLT N4 013 10 033 N4 0904 09	66.		ADOPTER N4 024 8 007 N4 024 9 007
67.		SPACER N4 013 22004 N4 013 36 005 N4 013 37 004 N4 013 38 004	68.		SPACER N4 013 10 032 N4 0904 07

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

69.		SPACER N4 013 10 022 N4 0904 18	70.		WASHER N4 024 8 003 N4 024 9 003
71.		NUT N4 024 8 008 N4 024 9 008	72.		TAPE GUIDE N4 039 2 008 N4 2322 08
73.		COMPENSATOR WIRE N4 009 3008 N4 1100 08	74.		COMPENSATOR SPRING N4 009 3013 N4 1100 13
75.		SPRING HOLDER N4 009 3014 N4 1100 14	76.		COMPENSATOR ARM OLD MODEL
77.		SPRING SHORT OLD MDOEL	78.		SPRING LONG OLD MODEL
79.		SPRING HOLDER OLD MODEL	80.		SPRING HOLDER ARM OLD MODEL
81.		HEILD WIRE N4 024 5 010	82.		MAILLION-160C N4 009 3017 N4 1100 17
83.		SPRING N4 013 30009 N4 0909 09	84.		SPRING N4 013 22006 N4 013 36 006 N4 013 37 006 N4 013 38 006 N4 013 40 002
85.		SPACER N4 020 2 014 N4 020 2 006	86.		MAGNET N4 0950 07
87.		COLLAR EYELET N4 013 22022 N4 013 36 023 N4 013 39 007 N4 0905 06	88.		FOAMED RUBBER N4 012 7007 N4 1401 12 N4 1407 12

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

89.		MAGNETIC SENSOR N4 010 6 013	90.		ELECTRO MAGNETIC CLUTCH
91.		N4 027 100 09 SPROCKET-20T ELE. MAGNETIC CLUTCH CENTER TEETH	92.		EXCENTER/CAM N4 024 11 001
93.		SHUTTLE SKIK-RH N4 013 10 041	94.		SHUTTLE SKID-LH N4 013 10 042
95.		WHITE NAMDA N4 013 30013 N4 0909 12	96.		MAXI DRAG CLOTH N4 036 9 007 N4 036 14 007 N4 1403 23
97.		EMERY CLOTH N4 2003 06 N4 2711 18	98.		GREASE NIPPLE 45 N4 024 8 023 N4 024 9 023
99.		CLAMP RING N4 2310 04 N4 039 3 004 N4 2316 04	100.		FLANGE N4 006 2 005
101.		SLIDING PART FIXED RETAINER N4 006 3 025	102.		SLIDING PART MOVEABLE RETAINER N4 006 3 014
103.		CALIPER CONE N4 006 3 028	104.		SPRING HOLDER N4 006 3 019
105.		ALUMINIUM ROLLER N4 012 7 006	106.		ADJUSTING RING N4 012 7 005

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

