

CATALOG OF LOHIA STARLINGER MODEL : LSL-6 CIRCULAR LOOMS SPARES (36 BELTS)

- | | | | | | |
|-----|---|---|-----|--|--|
| 1. |  | HEDDLE BELT
(1070 X 98 X 10)
LSL6 0738 08 | 2. |  | HEDDLE BELT
(1090 X 98 X 10)
SPECIAL SIZE |
| 3. |  | UPPER HEDDLE BELT
230 X 98 X 10
236 X 98 X 10
240 X 98 X 10
248 X 98 X 10
LSL6 0748 07 | 4. |  | LOWER HEDDLE BELT
455 X 98 X 10
460 X 98 X 10
465 X 98 X 10
470 X 98 X 10
475 X 98 X 10
485 X 98 X 10
LSL6 0748 20
LSL6 0761 20 |
| 5. |  | SHUTTLE BODY-P
LSL6 4925 15
LSL6 5996 15
LSL6 9906 15 | 6. |  | SHUTTLE BODY
PLASTIC
WITH SIDE FLANGE
ASSLY. |
| 7. |  | SHUTTLE BODY-AP
LSL6 9994 18
LSL6 9968 17
LSL6 0987 18 | 8. |  | SHUTTLE BODY
WITH SIDE FLANGE
COMP. ASSLY. |
| 9. |  | JOCKEY LEVER-S
(Brg.6001) ALUM.
LSL6 0625 15
LSL6 0634 15 | 10. |  | JOCKEY LEVER ASSY.-S
(LSL6-36 BELT)
ALUM. |
| 11. |  | STOPPER FRAME
COMPLETE | 12. |  | DRIVE FRAME
COMPLETE |
| 13. |  | CAM ROLLER-S
DIA-45MM
(Brg.6001)
LSL6 0625 06
LSL6 0634 06 | 14. |  | CAM ROLLER-S
(ASSEMBLY) DIA-
45MM |

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



- | | | | | | |
|-----|---|--|-----|--|---|
| 15. |  | CHONCHOID
ROLLER-P (Brg.6000
& 6001)
LSL6 9945 03 | 16. |  | CHONCHOID ROLLER-
P (ASSEMBLY) |
| 17. |  | STOPPER WHEEL-P
(Brg.6001)
LSL6 9945 11 | 18. |  | STOPPER WHEEL-P
(ASSEMBLY) |
| 19. |  | CHONCHOID ROLLER
(Brg.6001)
LSL6 995610 | 20. |  | CHONCHOID ROLLER
(ASSEMBLY) Brg.6001 |
| 21. |  | STOPPER ROLLER
(Brg.6001)
LSL6 9956 11 | 22. |  | STOPPER ROLLER
(ASSEMBLY) Brg.6001 |
| 23. |  | SHUTTLE WHEEL-P
(Brg.6001)
LSL6 9945 14 | 24. |  | SHUTTLE WHEEL-P
(ASSEMBLY) |
| 25. |  | SHUTTLE WHEEL
(Brg.6001)
LSL6 995605 | 26. |  | SHUTTLE WHEEL
(ASSEMBLY) |
| 27. |  | SWINGING LEVER
ASSEMBLY (NEW)
LSL6 0625 10
LSL6 0625 10a
LSL6 0634 10
LSL6 0634 10a | 28. |  | SHUTTLE ROLLER
MOUNTING - P
(ASSEMBLY) |

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



29.		SHUTTLE ROLLER-P (Brg.6001) LSL6 5990 04 LSL6 5996 07 LSL6 9994 04 LSL6 9906 07	30.		SHUTTLE ROLLER-P (ASSEMBLY)
31.		PUSHER ROLLER (Brg.6000) LSL6 0809 01	32.		PUSHER ROLLER (ASSEMBLY)
33.		BANDAGE MOLDING 6°(Brg.609) LSL6 080111 LSL6 080211 LSL6 080411	34.		BANDAGE MOLDING 6°(ASSEMBLY)
35.		STOPPER WHEEL - STEEL (Brg.609) LSL6 0814 08 LSL6 0805 08	36.		STOPPER WHEEL - STEEL (ASSEMBLY)
37.		STOPPER WHEEL - NYLON (Brg.609) LSL6 0805 08	38.		STOPPER WHEEL - NYLON (ASSEMBLY)
39.		LEVER HOLDER LSL6 5997 12 LSL6 5960 12	40.		WEFT COMPENSATION LEVER (MAGNET) LSL6 5997 02 LSL6 5960 02
41.		LEVER HOLDER (ASSEMBLY)	42.		COMPLETE CREEL ASSEMBLY
43.		DEF. PULLEY (98MM) CURVED (ASSEMBLY)	44.		DEF. PULLEY (98MM) CURVED LSL6 0738 09 LSL6 0748 09 LSL6 0761 09

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



45.		DEF. PULLEY- SMALL (84MM) STRAIGHT (ASSEMBLY)	46.		DEF. PULLEY (84MM) STRAIGHT Ref : LSL6 0738 20 Ref : LSL6 0748 24 Ref : LSL6 0761 24
47.		BOBBIN FLANGE - P 113MM ID 35MM LSL6 9947 12a LSL6 9968 20a	48.		BOBBIN FLANGE ASSY. - 113MM FOR PIPE ID - 35MM LSL6 9947 12 LSL6 9968 20
49.		BOBBIN FLANGE - P 100MM ID - 35MM LSL6 9947 12a LSL6 9968 20a	50.		BOBBIN FLANGE - P ASSY. 100MM ID - 35MM LSL6 9947 12a LSL6 9968 20a
51.		FLANGE WASHER (SOFT + HARD)- P(113MM) Ref : LSL6 994712b,c Ref : LSL6 9968 20b,c	52.		FLANGE WASHER (SOFT + HARD)-P (100MM) LSL6 9914 21 c,d LSL6 9923 20 c,d LSL6 9929 20 c,d
53.		BOBBIN DISC WITH BUSH LSL6 2358 01	54.		CREEL ADAPTER WITH BUSH LSL6 2358 03
55.		BOBBIN DISC-S LSL6 2358 01a	56.		CREEL ADAPTER-S LSL6 2358 03a
57.		BOBBIN DISC WITH BUSH LSL6 2316 01	58.		TUBE WITH FEATHER LSL6 2316 02a
59.		CONNECTING PLATE LSL6 0738 13 LSL6 0748 13 LSL6 0761 13 LSL6 0715 13 LSL6 0716 17	60.		BUSH LSL6 2358 01b LSL6 2358 02 LSL6 2358 03b

-: Registered Office Address :-

















7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

61.		CONNECTING STRIP LSL6 0738 14 LSL6 0748 14 LSL6 0761 14 LSL6 0716 16	62.		BRAKE BEARING LSL6 9924 06 LSL6 9946 07
63.		TENSION PAD-P LSL6 9946 03 LSL6 9924 03	64.		BEARING BLOCK (REAR)-P LSL6 5996 02 LSL6 9906 02
65.		BOOM HOLDER LSL6 5996 21 LSL6 9906 21 LSL6 4925 21	66.		BOOM MAGNET ASSY. LSL6 99270 3a
67.		COMPLETE MAGNET HOLDER ASSLY	68.		REFLECTOR HOLDER LSL69927 03
69.		INSERTION FINGER CERAMIC-INDIAN LSL6 5997 21	70.		INSERTION FINGER CERAMIC-IMPORTED LSL6 5997 21
71.		CLAMP-SHUTTLE GUIDE LSL6 5996 05 LSL6 9906 05 LSL6 4925 21	72.		CLAMP LSL6 5996 04 LSL6 9906 04 LSL6 4925 04
73.		CLAMP (LEFT) LSL6 5996 13 LSL6 9906 13 LSL6 4925 13	74.		CLAMP (RIGHT) LSL6 5996 14 LSL6 9906 14 LSL6 4925 14
75.		HOLDING BRACKET LSL6 7388 08	76.		FLANGE LSL6 0802 09 LSL6 0804 09

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
 AHMEDABAD-380004. Gujarat, INDIA.



77.		COMPENSATOR SEPARATOR LSL6 1117 08	78.		BEARING LSL6 1447 23 LSL6 1446 23 LSL6 6408 23 LSL6 6460 23
79.		SPRING HOLDER-S LSL6 5997 04 LSL6 5960 04	80.		SPRING HOLDER-P LSL6 5997 10 LSL6 5960 10
81.		BUSH FOR SPRING LSL6 9924 10 LSL6 9924 12 LSL6 9946 04 LSL6 9946 13	82.		CAP (CAM ROLLER) LSL6 9956 08
83.		ROLLER CAP LSL6 0625 01 LSL6 0634 15	84.		SHUTTLE ROLLER CAP-P LSL6 5990 05 LSL6 5996 10 LSL6 9994 05 LSL6 9906 10
85.		SHUTTLE WHEEL CAP LSL6 9956 01	86.		CHONCHOID CAP-P LSL6 9945 01 LSL6 9973 01
87.		PIVOT CAP - 36 LSL6 0625 13 LSL6 0634 13	88.		COMPLETE - PICK UP ASSY. LSL6/LXL6 WITH FOLDING INS. FINGER BIG 425mm
89.		COMPLETE - PICK UP ASSY. (LSL6/LXL6) WITH FOLDING INS. FINGER M. 366mm	90.		COMPLETE - PICK UP ASSY. LSL6/LXL6 WITH FOLDING INS. FINGER SMALL 308mm
91.		COMP. -PICK UP ASSY. LSL6/LXL6 WITH INS. PIPE P1- 308MM & CERAMIC BOW	92.		COMP. - PICK UP ASSY. LSL6/LXL6 WITH INS. PIPE P2-350MM & CERAMIC BOW

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



93. COMP. - PICK UP
ASSY. LSL6/LXL6
WITH INS. PIPE (P3-
258MM) & CERAMIC
BOW



94. COMP. - PICK UP ASSY.
LSL6/LXL6 WITH INS.
PIPE P4-230MM &
CERAMIC BOW



95. COMP. - PICK UP
ASSY. LSL6/LXL6
WITH INS. PIPE (P1-
308MM) & M. BOW



96. COMP. - PICK UP ASSY.
LSL6/LXL6 WITH INS.
PIPE P2-350MM & M.
BOW



97. COMP. - PICK UP
ASSY. LSL6/LXL6
WITH INS. PIPE (P3-
258MM) & M. BOW



98. COMP. - PICK UP ASSY.
LSL6/LXL6 WITH INS.
PIPE P4-230MM & M.
BOW



99. INS. FINGER - L
(P)425 MM
LSL6 0910 01



100. INS. FINGER - M
(P) 366 MM
LSL6 0910 02



101. INS. FINGER - S
(P) 308 MM
LSL6 0910 03



102. INS. PIPE-P1 308mm
LSL6 596019
LSL6 5997 15
LSL6 9948 17



103. INS. PIPE-P2-350
LSL6 5960 17
LSL6 5997 16
LSL6 9948 16



104. INS. PIPE - P3 258mm
LSL6 5960 18
LSL6 5997 17
LSL6 9948 18



105. INS. PIPE -P4 230
LSL6 5960 19
LSL6 5997 18
LSL6 9948 19



106. INSERTION FINGER
(200 MM)
LSL6 9927 11



107. INSERTION FINGER
(250 MM)
LSL6 9927 01
LSL6 9927 09



108. INSERTION FINGER
(300 MM)
LSL6 992710

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



109.		INSERTION FINGER - XL (335MM) LSL6 992712	110.		INSERTION FINGER CERAMIC LSL6 5997 21
111.		INSERTION FINGER- S LSL6 5960 01	112.		CYLINDRICAL PIN-S (2 X 8) LSL6 5997 05 LSL6 5960 05
113.		CYLINDRICAL PIN-P (2 X 14) LSL6 5997 11 LSL6 5960 11	114.		BOBBIN HOLDER-P (FLOATING END)Brg.6000 LSL6 9947 09
115.		BOBBIN HOLDER-P (FIXED END) Brg.6000 LSL6 9947 02	116.		BOBBIN HOLDER (Brg.6000) LSL6 996802
117.		BOBBIN HOLDER (FIXED END) Brg.6000 LSL6 9968 10	118.		COVER LSL6 9968 08
119.		PIVOT PIN LSL6 5997 14 LSL6 5960 14	120.		SPACER PUSHER ROLLER LSL6 0809 04
121.		ECCENTRIC ADAPTER (Brg. 6001) LSL6 9945 15	122.		EXCENTER BOLT (Brg. 6001) LSL6 9956 07
123.		CHONCHOID ADAPTER-P (Brg. 6000 & 6001) LSL6 9945 08	124.		ADOPTER (CHONCHOID ROLLER) (Brg. 6001) LSL6 9956 12

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



125.		STOPPER WHEEL ADAPTER-P (Brg. 6001) LSL6 9945 12	126.		ADOPTER (STOPPER ROLLER) (Brg. 6001) LSL6 9956 13
127.		COVER FRONT - P LSL6 9947 01 LSL6 9971 01	128.		COVER BACK - P LSL6 9947 04 LSL6 9971 05
129.		SPACER LSL6 0805 07 LSL6 0814 07	130.		SPACER LSL6 0802 08 LSL6 0804 08 LSL6 0801 08
131.		SPECIAL BOLT LSL6 0802 12 LSL6 0804 12 LSL6 0801 12	132.		ROLLER SPACER LSL6 9945 13
133.		NILOS RING LSL6 0625 17 LSL6 0634 17	134.		CAP LSL6 080215 LSL6 080415
135.		CAP LSL6 0805 11 LSL6 0814 11	136.		WASHER LSL6 0625 03 LSL6 0634 03 LSL6 9945 09 LSL6 9945 17
137.		SPL. WAHSER-M6 LSL6 4925 24	138.		SPACER LSL6 9968 11
139.		CHONCHOID SPACER-P LSL6 9945 06	140.		SPACER LSL6 9968 04

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.




141.		SPACER LSL6 0904 15 LSL6 9954 15	142.		SPL. NUT LSL6 5990 02 LSL6 9994 02
143.		ADAPTER LSL6 0625 07 LSL6 0634 07	144.		SPL. SCREW LSL6 0738 01 LSL6 0748 01
145.		SPRING STRETCHER- P LSL6 9946 11	146.		SPRING STRETCHER LSL6 9924 08
147.		COVER - PUSHER ROLLER LSL6 0809 05	148.		PIVOT PIN (12 X 57) LSL6 0625 11 LSL6 0634 11
149.		CYLINDRICAL PIN 5X 30 LSL6 5996 20 LSL6 9906 20	150.		DOWEL PIN- 6 X 30 LSL6 0738 16 LSL6 0748 16 LSL6 0761 16
151.		PIN - 4 X 20 LSL6 9927 04	152.		SOLID DOWEL PIN (6 X 10) LSL6 0814 06a LSL6 0809 10 LSL6 0802 13 LSL6 0804 13
153.		SOLID DOWEL PIN (6 X 12) LSL6 0814 06a LSL6 0809 10 LSL6 0802 13 LSL6 0804 13	154.		AXLE (SMALL) 84MM LSL6 0738 21 LSL6 0748 25 LSL6 0761 25
155.		AXLE - 98MM LSL6 0738 10 LSL6 0748 10 LSL6 0761 10	156.		ECCENTRIC AXLE-P LSL6 5996 11 LSL6 9906 11

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.























157.		ECCENTRIC AXLE-AP LSL6 9994 17	158.		ECCENTRIC AXLE M6 LSL6 4925 11
159.		UPPER BEARING BLOCK - 98MM LSL6 0738 05 LSL6 0748 05 LSL6 0761 05	160.		LOWER BEARING BLOCK-S 84MM LSL6 0738 18 LSL6 0748 18 LSL6 0761 18
161.		DRIVE FRAME LSL6 0801 07 LSL6 0809 07	162.		STOPPER FRAME LSL6 814 06
163.		BEARING BLOCK FRONT LSL6 9968 14	164.		BEARING BLOCK REAR Ref : LSL6 9968 15
165.		CLAMP (WARP GUIDE) LSL6 9968 16	166.		CLAMP (SHUTTLE GUIDE) LSL6 5990 12 LSL6 9994 12
167.		AXLE (FLOATING END)-P LSL6 9947 06 LSL6 9971 07	168.		AXLE LSL6 9968 07
169.		AXLE (FIXED END) LSL6 9968 09	170.		GRIP RING/CLAMP RING DIA 8MM LSL6 2358 03b
171.		EXPANDING RING-P LSL6 9947 12e LSL6 9968 20e	172.		STEEL RING-P LSL6 9968 20d LSL6 9947 12c

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



















173.		SPRING/ TEN. PAD LSL6 9924 11	174.		SPRING/BOBBIN HOLDER LSL6 9947 07 LSL6 9968 06 LSL6 9971 08
175.		SPRING FOR PICK UP (LOW DENIER-1) LSL6 5997 06 LSL6 5960 06	176.		SPRING FOR PICK UP (LOW DENIER-2) LSL6 5997 07 LSL6 5960 07
177.		SPRING FOR PICK UP (MEDIUM DENIER) LSL6 599708 LSL6 596008	178.		SPRING FOR PICK UP (HEAVY DENIER) LSL6 599709 LSL6 596009
179.		COMPENSATOR SPRING LSL6 1117 16	180.		SPRING HOLDER LSL6 1117 18
181.		SPRING LSL6 1435 06 LSL6 1661 06	182.		PRESSURE SPRING LSL6 1813 12
183.		INS. FINGER HOLDER LSL6 9926 01	184.		WARP GUIDE-P LSL6 5996 01 LSL6 9906 01
185.		SHUTTLE GUIDE-P LSL6 5996 19 LSL6 9906 19 LSL6 4925 19	186.		WARP GUIDE-AP LSL6 9994 01 LSL6 5990 01
187.		SHUTTLE GUIDE-AP LSL6 9994 11 LSL6 5990 11	188.		WEFT GUIDE LSL6 5990 20 LSL6 9968 18
189.		WEFT GUIDE (24") LSL6 4960 01	190.		THREAD EYE LSL6 1117 15b LSL6 1114 07b
191.		COMPENSATOR LSL6 1117 15 LSL6 1117 15a	192.		COMPENSATOR LSL6 1114 07

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.





193.		HEALD WIRE - 300 MM LSL6 0748 22	194.		HEALD WIRE - 310 MM LSL6 0761 22
195.		TAPE GUIDE/DROP WIRE (SINGLE TWIST) LSL6 2322 08 LSL6 7388 03	196.		THREAD WEIGHT (DOUBLE TWIST) LSL6 2322 08
197.		GUIDE ROLLER INSERT LSL6 7301 21d	198.		ADAPTER LSL6 6407 01
199.		SPACER FOR FINNED ROLLER LSL6 7701 24	200.		INDUCTION MOTOR 0.18 KW,380V,1500 RPM LSL6 3626 06
201.		SPROCKET 13T (IDLER) LSL6 2083 11 LSL6 2085 02 LSL6 2087 02	202.		SPROCKET 15T (IDLER) SIDE TEETH LSL6 2746 02 LSL6 1313 09 LSL6 1317 09
203.		SPROCKET 15T (DRIVE) - 20 MM ID LSL6 2747 10	204.		SPROCKET 15T (DRIVE) - 30 MM ID LSL6 1315 10
205.		SPROCKET 16T (DRIVE) - 30 MM ID LSL6 2023 16	206.		SPROCKET 20T (DRIVE) - 20 MM ID LSL6 7703 10
207.		SPROCKET 20T (DRIVE) - 30 MM ID LSL6 2082 08	208.		SPROCKET 20T (E M CLUTCH) CENTRE TEETH LSL6 1316 12 LSL6 1302 12

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



209.		SPROCKET 16T(SM) LSL6 2083 05 LSL6 7040 05	210.		SPROCKET 20T(SM) LSL6 2083 04 LSL6 7040 04
211.		SPROCKET 23T (DRIVE) - 30 MM ID LSL6 7045 08	212.		SPROCKET 39T (DRIVE) - 30 MM ID LSL6 7703 05
213.		SPROCKET 41T (DRIVE) - 30 MM ID LSL6 7703 06	214.		SPROCKET 41T (SENSOR MOUNTING) LSL6 2084 01 LSL6 2083 01 LSL6 2082 09 LSL6 7045 09
215.		SPROCKET 41T (SENSOR MOUNTING) 2 HOLE & 2 THREAD LSL6 2053 01	216.		SPROCKET 45T (DRIVE) LSL6 1086 19
217.		WORM WHEEL LSL6 1315 23	218.		WORM WHEEL (39T) LSL6 3917 09
219.		GEAR Z=53 LSL6 3621 06	220.		HELICAL GEAR 67T LSL6 3917 29
221.		GEAR Z=88 LSL6 3621 19	222.		ELECTRO MAGNETIC CLUTCH LSL6 1302 15 LSL6 1316 15
223.		WORM GEAR SHAFT LSL6 1315 09	224.		WORM SHAFT LSL6 3917 28
225.		PINION SHAFT Z=10 LSL6 3621 15	226.		PINION SHAFT Z=24 LSL6 3917 16

-: Registered Office Address :-



















7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.



227.		PINION SHAFT Z=9 LSL6 3622 07 LSL6 3624 07	228.		SHAFT (HWG) LSL6 3917 08
229.		SHAFT (TMG) LSL6 3621 09	230.		SHAFT (EM CLUTCH) LSL6 1302 20
231.		FIXED RETAINER LSL6 1813 04	232.		MOVEABLE RETAINER LSL6 1813 11
233.		FLANGE (FOR HDN6 CLOTH) LSL6 1813 15	234.		SPRING RETAINER LSL6 1813 13
235.		MOTOR PULLEY-I & II (OD-96.5 & 105.6MM) LSL6 1086 17 LSL6 1086 18 LSL6 1047 17 LSL6 1047 18	236.		COUNTER PULLEY (Brg. 6206) - ID 62MM LSL6 1031 04 LSL6 1041 04 LSL6 1086 04
237.		CREEL BRACKET WITH EYELET LSL6 7388 05	238.		CREEL BRACKET WITH EYELET LSL6 7388 04
239.		FLATTENER ARM LSL6 1813 05	240.		SPREADER ARM LSL6 1813 09
241.		EXTENSION ROD-EX LSL6 1813 01	242.		ALUM. PIPE (FOR SPONGE ROLLER) LSL6 1447 24 LSL6 1446 24 LSL6 6425 24
243.		ADJUSTING RING LSL6 1447 26 LSL6 1446 26 LSL6 6425 26	244.		GUIDE ROLLER LSL6 1448 01 LSL6 6407 01

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

245.		ADJUSTING SCREW LSL61435 05 LSL61461 05	246.		TENSION BELT LSL6 1461 12 LSL6 1435 12
247.		SPONGE ROLLER (21 X 63 X 150) LSL6 1447 25 LSL6 1446 25 LSL6 6460 25	248.		WOOLEN FELT CAP LSL6 0748 17 LSL6 0761 17
249.		MAGNET - 13 X 10 LSL6 9927 07	250.		NAMDA PAD LSL6 9924 01 LSL6 9946 01
251.		COMB HOLDER LSL61405 01	252.		SINTERED BUSH (6 X 12 X 12) LSL6 0625 10b LSL6 0634 10b
253.		SPECIAL NUT LSL6 5997 22	254.		CERAMIC EYLET LSL6 2322 06 LSL6 7388 04b LSL6 7388 05b
255.		V BELT (XPA-1557 L) LSL6 1086 11 LSL6 1057 11	256.		V BELT (XPA-1950 L) LSL6 1086 12 LSL6 1057 12
257.		SHAFT LSL6 7701 14c	258.		COM. FINNED ROLLER LSL6 7301 21 LSL6 7701 14
259.		FINNED ROLLER LSL6 7300 21	260.		SIMPLEX ROLLER CHAIN 3.048 MTR 1/2" X 5/16"
261.		CHAIN LOCK (1/2" X 5/16")	262.		EMERY CLOTH 100 MM (SQUARE)

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

263.		EMERY CLOTH 100 MM (SQUARE) SOFT - FOR HDEP	264.		EMERY CLOTH 50 MM (SQUARE)
265.		EMERY CLOTH 50 MM (SQUARE)	266.		EMERY CLOTH 100 MM (ROUND)
267.		EMERY CLOTH 50 MM (ROUND)	268.		EMERY CLOTH 100 MM (SAND)
269.		EMERY CLOTH 50 MM (SAND)	270.		MAXIDRAG 100 MM
271.		MAXIDRAG 50 MM	272.		PUSHER ROLLER (ASSEMBLY) Brg.6000
273.		SPACER LSL6 1102 19 LSL6 1114 06	273.		LOCK NUT KM-5 LSL6 1302 25 LSL6 1316 25
275.		ECCENTRIC AXLE-AP LXL6 9994 03	276.		MOTOR LSL6 1068 16
277.		ISOLATION TRANSFORMER (500 VA) LSL6 1637 07	278.		CONTROL TRANSFORMER (165 VA) LSL6 1637 08
279.		ON OFF SWITCH 3 POLE WITH TEAR DROP KNOB LSL6 1634 13	280.		ROTARY SWITCH 3 POLE 16 AMP LSL6 1634 14

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
AHMEDABAD-380004. Gujarat, INDIA.

281.		EMERGENCY STOP BUTTON LSL6 0402 07	282.		PILOT LAMP GREEN (24V) LSL6 1647 16
283.		PILOT LAMP RED (24V) LSL6 0402 01	284.		PUSH BUTTON ACTUATOR GREEN LSL6 0402 09
285.		MAGNETIC SENSOR MB80-12GM50-E0 (P&F) NPN LSL6 1217 05 LSL6 1227 05 LSL6 1238 05 LSL6 1210 09	286.		MAGNETIC SENSOR MB80-12GM50-E2 (P&F) PNP LSL6 1217 05 LSL6 1227 05 LSL6 1238 05 LSL6 1210 09
287.		COLOUR SENSOR OBT-200-18GM60-E5 (P&F) PNP LSL6 1212 09 LSL6 1215 09 LSL6 1225 10 LSL6 1228 10	288.		PROXIMITY SENSOR WITH 6 MTR. CABLE ELEC. COU METER LSL6 2035 06 LSL6 2084 08
289.		PROXIMITY SENSOR WITH 8 MTR CABLE LSL6 1065 09 LSL6 1215 20	290.		PROXIMITY SENSOR NBB2-8GM30-E2- V1 WITH CONNECTOR (P&F) PNP LSL6 7026 05
291.		ELECTRONIC COUNTER METER LSL6 1648 05	292.		W. E. LOGIC CARD LSL6 1215 21 LSL6 1228 18
293.		RELAY PCB ASSEMBLY (LSL6M) LSL6 9614 51	294.		WARP BREAK SENSOR MODULE LSL6 1637 06

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road,
 AHMEDABAD-380004. Gujarat, INDIA.



295. COMBINATION CARD / WEFT END + LOGIC CARD PCB A LSL6 1637 33



296.

BEARING BLOCK FRONT - P LSL6 9906 12



297.

ALL SIZE HEX HEAD BOLT



298.

ALL SIZE ALLEN SOCKET HEAD CAP SCREW



299.

ALL SIZE ALLEN CAP BUTTON HEAD SCREW



300.

ALL SIZE ALLEN GRUB SCREW



301.

ALL SIZE ALLEN CSK HEAD SCREW



302.

ALL SIZE HEX ZN. PLTD NUT



303.

ALL SIZE NYLOCK NUT



304.

INTERNAL STAR WASHER FOR CONNECTING ROD



305.

ALL SIZE ZN. PLTD. PLAIN WASHER



306.

ALL SIZE INT./EXT./E-TYPE CIRCLIPS



307.

REED RING COMPLETE ASSY.



308.

REED SAMM & BIG



309.

MAIN CAM



310.

A.C. DRIVE



311.

ALL SIZE ALUMINIUM WEAVING RING



312.

MAGNET HOLDER LSL6 9927 08

-: Registered Office Address :-

7, C. M. Shah Complex, Near Hanumanpura, Opp. Jupiter Textile Mills, Dudheshwar Road, AHMEDABAD-380004. Gujarat, INDIA.

